

MIE 240: Human-centred system design

Applying design guidelines



0


Learning Objectives

- Review design guidelines for attention, working memory, long-term memory, & decision-making
- Discuss examples of design shortcomings and areas of improvement



1

Skill in Decision Making	Less Proficient (Novice)	Very Proficient (Expert)
Reasoning Level	Knowledge-based	Rule-based Skill-based
Decision Type	Analytic	Intuitive
Decision System	System 2	System 1
School of Decision Research	Heuristic and Biases "What's wrong"	Naturalistic Decision Making "What's right"
Adaptive Decision Making	Less	More


 Increasing Experience

Last Lecture

- Decision-making
 - Characteristics
 - Normative and descriptive decision making
 - Heuristics and biases
- Introduced knowledge, rule, skill model
- Discussed design guidelines for decision-making



Design implications

Selective attention

1. Optimize bottom-up processing
2. Support automaticity and unitization
3. Optimize top-down processing
4. Maximize discriminating features

Working Memory

1. Minimize working memory load
2. Provide visual echoes
3. Provide placeholders for sequential tasks
4. Exploit chunking
5. Minimize confusability
6. Avoid unnecessary zeros
7. Ensure congruence of instructions
8. Avoid negation

• A ALPHA	N NOVEMBER
• B BRAVO	O OSCAR
• C CHARLIE	P PAPA
• D DELTA	Q QUEBEC
• E ECHO	R ROMEO
• F FOXTROT	S SIERRA
• G GOLF	T TANGO
• H HOTEL	U UNIFORM
• I INDIA	V VICTOR
• J JULIET	W WHISKY
• K KILO	X X-RAY
• L LIMA	Y YANKEE
• M MIKE	Z ZULU

Phonetic alphabet


Design Implications

Long-term memory

1. Encourage regular use
2. Encourage active reproduction
3. Use memory aids - place "Knowledge in the world"
4. Support correct mental models
5. Standardization

Decision-making

1. Task redesign
2. Choice architecture
3. Proceduralization
4. Training decision-making
5. Use displays
6. Automation and decision support tools



4

Examples



5


5

Keep in mind

Design implications

- Selective attention
- Working memory
- Long-term memory
- Decision-making

The Hierarchy of Intervention Effectiveness



MIE240: Human-Centred Systems Design

6



6

Dosing instructions

A		B	
Start	Medication	Start	Medication
Stop		Stop	
Current Status		Current Status	
20/02/21 1030	Rx R000004815 HYDROmorphone (10 mg/mL) 1,000 MG in 100 ML CASSETTE	03/12/20 1020	Rx R000004588 HYDROmorphone (10 mg/mL) 1,000 MG in 100 ML CASSETTE
06/03/21 1029		13/12/20 1044	
Active		Active	
<input type="checkbox"/> <input type="checkbox"/> Dose Instructions Continuous Rate		<input type="checkbox"/> <input type="checkbox"/> Dose Instructions Concentration: 10 mg/mL Continuous Rate: 4 ag/Hour	
		<input type="checkbox"/> <input type="checkbox"/> Linked Orders	
20/02/21 1030	Rx R000004816 HYDROmorphone (10 mg/mL) 1,000 MG in 100 ML CASSETTE	03/12/20 1015	Rx R000004587 HYDROmorphone (10 mg/mL) 1,000 MG in 100 ML CASSETTE
06/03/21 1029		17/12/20 1014	
Active		Active	
<input type="checkbox"/> <input type="checkbox"/> Dose Instructions Demand Dose/Breakthrough Dose		<input type="checkbox"/> <input type="checkbox"/> Dose Instructions Breakthrough Dose: 2 ag/30 minutes AS NEEDED Doses Per Hour : 2 / hr	

7

Weight-based dosing

Dosing chart



Can be given:	Acetaminophen (such as Tylenol) every 4-6 hrs			Ibuprofen (such as Motrin or Advil) every 6-8 hrs			Diphenhydramine (such as Benadryl) every 6-8 hrs	
	Infant Dropper	Infant's and Children's	Chewable Tablets	Concentrate	Liquid	Chewable Tablets	Liquid	Mekavay Tablets
Concentration:	0.8mL = 80mg	5mL (1tsp) = 160mg	1 tablets = 80mg	1.25mL = 50mg	5mL (1tsp) = 100mg	1 tablets = 50mg	1tsp = 12.5mg	1 tablet = 12.5mg
Age:	2 Months or Older			6 Months or Older			6 Months or Older	
WEIGHT								
12-15 lbs	1 dropper (0.8 mL)	1/2 tsp (2.5 mL)		1.25 mL	2.5 mL		1/2 tsp	
15-19 lbs	1.25 droppers (1 mL)	3 mL		1.5 mL	3 mL		1/2 tsp	
19-24 lbs	1.5 droppers (1.2 mL)	3/4 tsp (4 mL)		2 mL	4 mL		3/4 tsp	
24-32 lbs	2 droppers (1.6 mL)	1 tsp (5 mL)	2 tablets	2.5 mL	5 mL	2 tablets	1 tsp	1 tablet
30-40 lbs	2.5 droppers (2 mL)	1 1/4 tsp (6 mL)	2.5 tablets	3.5 mL	1 1/2 tsp (7.5 mL)	3 tablets	1 1/4 tsp	1 1/4 tablets
38-48 lbs	3 droppers (2.4 mL)	1 1/2 tsp (7.5 mL)	3 tablets	4.25 mL	1 3/4 tsp (8.75 mL)	3 1/2 tablets	1 1/2 tsp	1 1/2 tablets
46-56 lbs	3.5 droppers (2.8 mL)	1 3/4 tsp (9 mL)	3.5 tablets	5 mL	2 tsp (10 mL)	4 tablets	2 tsp	2 tablets
54-64 lbs	4 droppers (3.2 mL)	2 tsp (10 mL)	4 tablets	6.25 mL	2 1/2 tsp (12.5 mL)	5 tablets	2 1/2 tsp	2 1/2 tablets

Many drugs (especially in children) are dosed according to body weight (mg/kg). These calculations are carried in 3-step conversions. The first step is to convert the body weight from pounds (lbs) to kg. The second step is to convert kg to mg (the total mg dose calculated based on body weight). Finally, the mg dose is converted to the number of tablets.

8

8

Weight-based dosing

Your weight

kg

Dosage

mg /kg

Frequency

once per day

Total daily dose

mg

Liquid medicine

Medicine concentration

4 mg/mL

Total liquid dose

ml

Send this result

9

9

Medication preparation



Medications stored in a kidney basin




Medication storage tray


10

Anesthesia labels

Challenges with selective attention in brain UI



Standard pharmacy labels




Icon-based labels

11

Anesthesia monitoring




Standard anesthesia machine



Proposed anesthesia machine design


12

Supporting assembly of chest retractors



13

Supporting assembly of chest retractors



Pictures of incorrect and correct assembly place in retractor book and at workstation

14

Supporting assembly of chest retractors




- Implemented hard stop in instrument management system (could not complete tray without supervisor approval)
- Supervisor verifies retractor assembled correctly

Assembly video included instrument management system

15

Radiology: reducing retained foreign objects



1


Is a retained foreign object present?




2

16

Radiology: reducing retained foreign objects



★ Possible abnormality




★ Possible abnormality

★ Abnormality detected

17

Radiology: reducing retained foreign objects



18

Next lecture (Tues. Jan 28)

Topic: Displays

Review: Ch 8.1 – 8.5, 8.7-8.9

Review questions: 8.1, 8.3, 8.6-8.18

Upcoming assignments: Case study: Act of God (due Jan 30th at 11:59pm)

21